

Crestron **CNMSX** (PRO & AV)
Integrated Control System

Operations Guide

Contents

Integrated Control System: CNMSX	1
Description	1
Functional Description	1
Configuration Differences	1
Physical Description	2
Leading Specifications	9
Setup	11
Rack Mounting	11
Bussing Strip Installation	12
Network Wiring	12
Hardware Hookup	14
Programming the LCD Display (available on CNMSX-PRO only)	15
Front Panel Editor	15
Creating a Simple Page with Front Panel Editor	16
Object Types	18
Loading Crestron Control Software	18
Installing Crestron Development Tools	18
Initial Setup	19
File Types	21
Obtaining Communications	23
Troubleshooting Communications	26
Loading the System Program	29
Testing the Permanent Memory Image	30
Loading Touchpanels	30
Updating the Control System	31
Special Consideration for Updating the Control System	33
Problem Solving	33
Possible Problems with the CNMSX	34
Serial Communication Difficulties with Other Devices Connected to the CNMSX	34
Further Inquiries	36
Return and Warranty Policies	37
Merchandise Returns / Repair Service	37
CRESTRON Limited Warranty	37

Integrated Control System: CNMSX

Description

Functional Description

The CNMSX is an integral part of Crestron's new generation of control system technology featuring the newest series of Ethernet/local area network (LAN) compatible control systems. The CNMSX is an integrated control system with eight infrared (IR)/serial ports, six bidirectional RS-232/422/485 ports, eight digital/analog input and digital output ports, eight isolated relays, and an integrated 110/220 VAC (75W) power supply.

Expansion Slots

There is also room for growth; the unit (depending on configuration) offers four expansion slots. One of the slots features Crestron's exclusive Direct Processor Access (DPA) port for Ethernet/LAN expansion of the control network. This port provides high speed access directly to the processor while maintaining bandwidth network connections. The DPA currently supports the CNXENET 10 BaseT Ethernet card with future support for Firewire, ATM, 100BaseT, and popular interfaces.

LCD Display (available on CNMSX-PRO only)

An 80-character (two 40-character lines) liquid crystal display (LCD) display and an extended bank of LED indicators are located on the front panel to provide extended features, status information, and troubleshooting indications.

Configuration Differences

There are two CNMSX configurations available: the PRO and AV. The PRO is the flagship product in Crestron's new generation of control systems. It is the model that has all the features mentioned in the previous section. The AV is a cost-competitive alternative to the PRO. The AV has all the features of the PRO, except for the extended bank of status and activity LEDs, front panel LCD screen, and the network analyzer feature. A "card cage" (CNXCAGE) providing three expansion slots is

optional on the AV. Refer to the table below for a concise list of configuration features.

CNMSX Configuration Differences


FEATURES	CNMSX-PRO	CNMSX-AV
Integrated 110/220 VAC Power Supply	Standard	Standard
2 Crestron Network Ports	Standard	Standard
8 Isolated Relays	Standard	Standard
8 IR/Serial Ports	Standard	Standard
6 Bidirectional RS-232/422/485 Ports	Standard	Standard
8 Digital/Analog Input & Digital Output Ports	Standard	Standard
2 Computer (RS-232) Ports	Standard	Standard
Direct Processor Access (DPA) Slot	Standard	Standard
Expansion Slots	Standard	Optional
CNXENET or CNXENET+ (field installed into DPA slot)	Optional	Optional
Reverse LCD Display	Standard	Not Available
Extended Bank of Status and Activity LEDs	Standard	Not Available
COM Analyzer	Standard	Not Available

Physical Description


An asterisk () indicates that the feature is not standard (though may be optional) on the AV configuration.*

The CNMSX is housed in a black enclosure with silk-screened labels on the front and rear panels. On the front panel there is a single RS-232 computer port, standard LEDs, two reset buttons, a reverse LCD display* with menu function and selection buttons, and an extended bank of LED indicators*. The front panel of the CNSMX-PRO and AV are shown below.

CNMSX-PRO Front Panel




CNMSX-AV Front Panel




An asterisk () indicates that the feature is not standard (though may be optional) on the AV configuration.*

Located on the rear panel, shown on the next page for each configuration, there are three open card slots*, two network connectors, DPA slot, a single RS-232 computer port, eight IR/serial ports, eight I/O ports, eight relay ports, six COM ports, and a 110/220 VAC male connector for power.

CNMSX-PRO Rear Panel with Optional DPA Expansion Card and Rack Mounting Ears Installed



CNMSX-AV Rear Panel with Optional DPA Expansion Card and Rack Mounting Ears Installed



Rubber feet are supplied and can be attached to the base of the unit for stability and to prevent slippage when resting on a flat surface. The unit may also be rack mounted by attaching metal flanges, also known as ears (supplied), to each end.


CNMSX Ports

A number of ports are provided on the front and rear panels of the CNMSX. Refer to the description of each below.

CRESNET

CRESNET 4-Wire and 6-Pin Connectors

CRESNET



On the rear panel there are two network connectors: 4-wire and modular. The 4-pin male connector (typical Crestron network port labeled 24 Y Z G) and 6-wire RJ-type connector are used for expansion to Cresnet and SmarTouch peripherals. Depending on the expansion slot load, there is a 50 W maximum load rating. The ports are wired in parallel.


NOTE: If using the 4-wire connector, review the latest revision of the network interconnection drawing (Doc. 5411).

NOTE: If using the modular connector, review the latest revision of the Network Modular Cable Requirements (Doc. 5682). Most 4-conductor phone cables are wired in a crisscross fashion and are not compatible with Crestron equipment.

The documents mentioned in the two preceding notes can be obtained from the Downloads page (CABLES and MANUALS Libraries) of the Crestron website (www.crestron.com). Search for the CRESNET.PDF and MODULAR.PDF files.

RELAY OUTPUT


Relay Output Connector



On the rear panel there are eight normally open, isolated relays. Each relay is rated 1A, 30 VAC/DC; MOV arc suppression is provided across contacts for use with “real world” loads.

I/O


I/O Connector



On the rear panel there are eight software programmable analog and digital inputs as well as digital outputs. Digital outputs offer 250mA sync from maximum 24 VDC; catch diodes for use with “real world” loads. Digital inputs are rated 0 - 24 VDC, 20K ohms input impedance, logic threshold 1.25 VDC. Analog inputs are rated 0 - 10 VDC, protected to 24 VDC maximum, 20K ohms input impedance; pin-programmable 2K ohms pullup resistor to +5V.

INFRARED - SERIAL - RS 232

Infrared - Serial Output Connector



On the rear panel there are eight serial outputs for IR, one-way RS-232, or serial interface. Each output is labeled S (signal) and G (ground). Infrared output is rated up to 1.2 MHz. Serial protocols include RS-232.

NOTE: RS-232 levels provide a 0 – 5V range, which may not be compatible with all devices.

COM (A - F)

COM (A - F) Connectors



On the rear panel there are six software programmable bidirectional serial ports for RS-232, RS-422, or RS-485 communication with hardware and software handshaking. Speeds are rated up to 230,400 bps.

NOTE: The pinout of each 9-pin port is non-standard (refer to table after this note, titled “Non-Standard COM Pinout”); it contains RS-422 pins in addition to RS-232.

This may result in a conflict with some equipment and therefore do not use all nine pins. Only the required pins for each communication type should be connected.

NOTE: To support RS-485, tie pin 1 (RXD-) to pin 9 (TXD-) and pin 4 (TXD+) to pin 6 (RXD+) in the cable (refer to table after this note, titled “COM Pinout to RS-485 Bus”).

Non-Standard COM Pinout

PIN	DIRECTION	DESCRIPTION
1*	To CNMSX	(RXD-) RS-422 Receive Data (Idles low)
2	To CNMSX	(RXD) RS-232 Received Data
3	From CNMSX	(TXD) RS-232 Transmitted Data
4	From CNMSX	(TXD+) RS-422 Transmit Data (Idles high)
5		RS-232 and RS-422 Signal Common
6	To CNMSX	(RXD+) RS-422 Receive Data (Idles high)
7	From CNMSX	(RTS) RS-232 Request to Send
8	To CNMSX	(CTS) RS-232 Clear to Send
9	From CNMSX	(TXD-) RS-422 Transmit Data (Idles low)


Where: *= RS-422 transmit and receive are balanced signals requiring two lines plus a ground in each direction. RXD+ and TXD+ should idle high (going low at start of data transmission). RXD- and TXD- should idle low (going high at start of data transmission). If necessary, RXD+/RXD- and TXD+/TXD- may be swapped to maintain correct signal levels.

COM Pinout to RS-485 Bus

COM (DB9) CONNECTOR	RS-485 BUS
Tie Pins 1 & 9	+
Tie Pins 4 & 6	-
Pin 5	G

COMPUTER

Computer Connectors




These 9-pin DB9 female connectors (one on front panel and one on rear) are used when programming with a PC. Each port is modem compatible. The modem cable is not included.

100 - 250V ~ 2.3A 50/60 Hz (Power Supply)

Universal Power Supply Connector

100-250V~ 2.3A
50/60 Hz



On the rear panel there is an internal universal power supply connector. Use the supplied power cord to connect to an AC outlet.

CNMSX Indicators

A number of indicators are provided on the front panel of the CNMSX. Refer to the description of each below.

PWR

This LED illuminates when the unit is connected to and receives power from an AC outlet.

NET

This LED illuminates when the central processing unit (CNXPU) is processing or communicating with system hardware (i.e., button pressed at local panel or network panel, data being sent out serial port, or permanent memory image being created).

ERR

This LED illuminates when an error condition is detected by the CNXPU. This may be the result of hardware or software failure, hardware incompatibility with software definitions, or a programming error. To decipher content, examine the message available from the menu function buttons.

NOTE: The next four LEDs are active only if the DPA Expansion Card (which is field installed) occupies the DPA slot.

TXD (LAN)

This LED illuminates during transmission of ethernet data from the DPA slot.

RXD (LAN)

This LED illuminates during reception of ethernet data by the DPA slot.

LNK (LAN)

This LED illuminates when there are attachments to the ethernet network.

ERR (LAN)

This LED illuminates when an ethernet protocol error is detected.

NOTE: The remaining LEDs mentioned after this note are available on the PRO configuration, but not available on the AV configuration.

COM TX (A - F)

These LEDs illuminate during transmission of data to serial devices attached to respective COM ports.

COM RX (A - F)

These LEDs illuminate during reception of data from serial devices attached to respective COM ports.

COM RTS (A - F)

These LEDs illuminate to reflect the state of RTS (A - F). When RTS flow control is enabled, RTS indicates the unit is ready to receive data from serial devices attached to respective COM ports.

COM CTS (A - F)

These LEDs illuminate to reflect the state of CTS (A - F). When CTS flow control is enabled, CTS indicates the serial devices on the respective COM ports are ready to accept data from the unit.

IR - SERIAL (A - H)

These LEDs illuminate during activity on respective IR/SERIAL lines.

INPUT - OUTPUT (1 - 8)

These LEDs illuminate when the input voltage threshold for respective I/O ports are exceeded or when the output is active.

RELAY (1 - 8)

These LEDs illuminate when respective relay is closed.

SLOT (1 - 3)

These LEDs illuminate when a CNX expansion card is inserted into respective slots.

CNMSX Buttons

Two buttons are provided on the front panel of the CNMSX. Refer to the description of each below.

HW-R

Depression of this button initiates physical reset of the system.

SW-R


Depression of this button in combination with the **HW-R** button (as described in step 5 of "Troubleshooting Communications" on page 26) performs an overload/reset.

CNMSX LCD Display

The front panel of the CNMSX-PRO incorporates a reverse mode (yellow on black) LCD display, shown below. The screen contains two lines with 40 characters per line; it is used to extend features and gain access to the system including the SIMPL program. To the right of the display are four menu selection buttons. These buttons permit the user to navigate through the menus and also to control the brightness of the display backlight. Below the display are six menu function buttons. These buttons offer extended features of the CNMSX. For details, refer to "Programming the LCD Display (available on CNMSX-PRO only)" on page 15.

Main Menu

LCD Display with Menu Selection and Menu Function Buttons



Menu Selection Buttons

MENU

This menu selection button functions as a return and will eventually bring the screen display to the menu default state.

^

This button scrolls the listed information UP.

v

This button scrolls the listed information DOWN.

BKLT

This button adjusts the brightness of the LCD backlight and the front panel LEDs.

Menu Function Buttons

PANEL

This menu function button displays a programmable interface offering command text, indirect text, and hierarchical screen structure. The menu contents are subject to programming and an example of this display is provided in "Programming the LCD Display (available on CNMSX-PRO only)" on page 15.

INFO

This button displays a default Info Menu, shown below. System information including the loaded SIMPL program, types of CNX cards installed into the CNMSX slots, the Cresnet devices detected, the Ops/ROM version, and the when the last program was saved.

Default Info Menu



MSG

This button displays system error messages or alarms. If there are one or more errors, press the v menu selection button to reveal the next message.

NOTE: Error messages may be the result of hardware or software failure, hardware incompatibility with software definitions, or a programming error. After the last message has been read, the ERR front panel LED extinguishes.

Example Message



TIME

This menu can only be obtained by entering the correct access code. The default access code is 1234. The default Time Menu, shown after this paragraph, permits alterations to system date and time. Selecting a date/time parameter from the menu increments it by one. Additional incremental or decremental changes can then be done by depressing the ^ and v menu selection buttons, respectively.

Default Time Menu



COM

This button monitors the transmission and reception traffic on each COM port for a given data format, as shown below in the default COM Menu. For more details refer to "Network Analyzer (available on CNMSX-PRO only)" on page 34.

Default COM Menu



Leading Specifications

The tables below and on the next page provide a summary of leading specifications for the CNMSX. Dimensions and weight are rounded to the nearest hundredth unit.

Leading Specifications of the CNMSX

SPECIFICATION	DETAILS
Power Requirements	100-250 VAC, 2.3 A, 50/60 Hz Internal Universal Power Supply
SIMPL™ Windows®	Version 1.30.01 or later with the addition of smwlib49.exe and smwlib49.txt. ¹
CNX Upgrade File	Version 5.09.07x.upz or later. ²
Reset Buttons	HW-R (permits physical reset of system) & SW-R (assists with overload/reset).

¹ The latest software versions can be obtained from the Downloads page (SIMPLWIN Library) of the Crestron website (www.crestron.com). New users are required to register in order to obtain access to the FTP site.

² Filenames for CNX upgrades have a UPZ extension and can be obtained from the Downloads page (OPSYS Library) of the Crestron website. For a CNMSX with e-control™ use the latest UPZ upgrade file from the ECONTROL Library.

Leading Specifications of the CNMSX (Continued)

SPECIFICATION	DETAILS
LCD Display	(1) reverse mode (yellow on black) LCD back light; (2) lines, (40) characters per line. ³
MaxDigitalSignals	16373
MaxAnalogSignals	2048
MaxNVRAM	64K
MaxProgramSize	256K (no DPA card installed, CNXENET+ card installed, or CNXENET installed and its IP Address set to 0.0.0.0) 100K (CNXENET card installed with valid IP Address) ⁴
Dimensions & Weight	Height: 3.47 in (8.81 cm) Width: 19.00 in (48.26 cm) Depth: 8.43 in (21.41 cm) Weight: 6.29 lb (2.85 kg) for AV Weight: 7.01 lb (3.18 kg) for PRO

³ The LCD display is not available on the CNMSX-AV.

⁴ The program size restriction of 100K with the CNXENET card exists if the control system has the CNXENET card installed and a valid IP address is assigned. SIMPL Windows limits the size of the compiled file to 100K **only** if the CNXENET card has been dropped onto the DPA Card slot.

Typically, if the CNXENET card is being used for remote maintenance and **not** for programming Ethernet devices (such as e-control touchpanels, etc), most users do not drop the CNXENET card into the program in SIMPL Windows. Please note that the maximum program size is **still** 100K, even though SIMPL Windows states 256K during a compile. To make SIMPL Windows enforce the restriction, drop a CNXENET card into the DPA Card slot.

Leading Specifications of the CNMSX Connectors

CONNECTOR	DETAILS
NET	(1) 6-wire RJ-type connector and (1) 4-pin male connector for expansion to CRESNET or SmarTouch peripherals. 50 Watt maximum load depending on expansion slot load
RELAYS	(8) normally open, isolated relays; each relay is rated 1 A, 30 VAC/DC MOV arc suppression devices across contacts for use with "real world" loads
INPUT/OUTPUT	(8) programmable digital/analog inputs & digital outputs; digital outputs offer 250 mA sync from maximum 24 VDC; catch diodes for use with "real world" loads; digital inputs rated for 0-24 VDC, 20 K ohms input impedance, logic threshold 1.25 VDC; analog inputs rated 1-10 VDC, protected to 24 VDC maximum, 20 K ohms input impedance; programmable 2 K ohms pullup resistor (per pin, software reference to GND or closure to GND)
IR/SERIAL	(8) serial outputs or IR, RS-232, or serial interface; signal (S) and ground (G) pins, infrared output up to 1.2 MHz, serial protocols include RS-232
COM	(6) bidirectional serial ports for RS-232, RS-422, or RS-485 communication with hardware and software handshaking; speeds up to 230,400 bps
COMPUTER	(2) 9-pin DB9 female connector for programming with a PC; modem compatible, null modem cable; not included

Leading Specifications of the CNMSX Slots

SLOT	DETAILS
1 through 3	(3) open "card cage" slots accept any "X" CRESNET control card ⁵
DPA	Direct Processor Access expansion slot for optional local area network (LAN) interface card; CNXENET+ requires field installation and has (1) 8-wire RJ45 connector for communication acces

⁵ CNXCAGE, 3-card cage, installation required for CNMSX-AV.

As of the date of manufacture, the unit has been tested and found to comply with specifications for CE marking.



NOTE: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Setup

Rack Mounting

WARNING: To prevent bodily injury when mounting or servicing this unit in a rack, take special precautions to ensure that the system remains stable. The following guidelines are provided to ensure your safety:


- The unit should be mounted at the bottom of the rack if it is the only unit in the rack.
 - When mounting this unit in a partially filled rack, load the rack from the bottom to the top with the heaviest component at the bottom of the rack.
 - If the rack is provided with stabilizing devices, install the stabilizers before mounting or servicing the unit in the rack.
-

NOTE: If rack mounting is not required, rubber feet are provided for table-top mounting or stacking. Apply the feet near the corner edges on the underside of the unit.

NOTE: Reliable earthing of rack mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit. (e.g., use of power strips).

Two “ears” are provided with the CNMSX so that the unit can be rack mounted. These ears must be installed prior to mounting. Complete the procedure below to attach ears to CNMSX. The only tool required is a #2 Phillips screwdriver.

1. There are 12 screws (#6-32 x 0.375" LG) that secure the sides of the CNMSX top cover. Using a #2 Phillips screwdriver, remove the three screws closest to the front panel from one side of the unit.
2. Position a rack ear so that its mounting holes align with the holes vacated by the screws in step 1.
3. Secure the ear to the CNMSX with three screws from step 1, as shown on the next page.

Ear Attachment for Rack Mounting

4. Repeat procedure (steps 1 through 3) to attach remaining ear to opposite side.

Bussing Strip Installation

The CNMSX is supplied with a brass bussing strip to facilitate commoning (linking) of multiple terminal block connections. The bussing strip is constructed with eight terminal block position, and may be trimmed to size for various applications or different devices. One strip is supplied for each 16-position terminal block.

1. To utilize the bussing strip, determine the number of relays to be commoned for the equipment being installed. If less than eight, the strip can be trimmed to size with a pair of scissors or wire snips.
2. Loosen the terminal block screws and insert the first leg of the bussing strip into the first common position on the terminal block. The strip engages the other common positions automatically.
3. Remove approximately 1/8" of the jacket from the common wire and insert the conductor into one of the terminal block common positions. Tighten the terminal block screws to lock the wire and bussing strip into place. Insulate the strip by folding a piece of 3/4 wide vinyl electrical tape (such as Scotch 33+) over the spine and as much of the individual legs as possible. Excess tape at each end of the strip should be pressed closed, then trimmed to within approximately 1/16" of the end of the strip.
4. When wiring the remaining conductors, remove approximately 1/8" of the jacket and insert the wires into the proper terminal block positions. To prevent the possibility of electrical shorts, it is essential that these conductors do not touch any uninsulated portion of the bussing strip.
5. Securing a tie wrap around the bussing strip is a useful way to strain relieve the wires connected to the terminal block.

Network Wiring

When calculating the wire gauge for a particular network run, the length of the run and the power factor of each network unit to be connected must be taken into consideration. If network units are to be daisy-chained on the run, the load factor of each network unit to be daisy-chained must be added together to determine the load factor of the entire chain. The length of the run in feet and the load factor of the run should be used in the resistance equation on the next page to calculate the value on the right side of the equation.

Resistance Equation

$$R < \frac{40,000}{L \times LF}$$

Where: R = Resistance (refer to table below).
 L = Length of run (or chain) in feet.
 LF = Load factor of entire run (or chain).

The required wire gauge should be chosen such that the resistance value is less than the value calculated in the resistance equation. Refer to the table below.

Wire Gauge Values

RESISTANCE (R)	WIRE GAUGE
4	16
6	18
10	20
15	22
13	24 (Doubled-CAT 5)


NOTE: All network wiring must consist of two twisted-pairs. One twisted pair is the +24V conductor and the GND conductor and the other twisted pair is the Y conductor and the Z conductor.

NOTE: When daisy chaining network units, always twist the ends of the incoming wire and outgoing wire which share a pin on the network connector. After twisting the ends, tin the twisted connection with solder. Apply solder only to the ends of the twisted wires. Avoid tinning too far up or the tinned end becomes brittle and breaks. After tinning the twisted ends, insert the tinned connection into the network connector and tighten the retaining screw. Repeat the procedure for the other three network conductors.

Four-Pin Network Connector

For four-pin network cable connections in a Crestron remote control system, the Cresnet cable is used to power Crestron devices. Before making any four-pin network connections to the CNMSX, refer to the network interconnection after this paragraph.

Recommended Network Cable, Liberty Wire Reference: Cresnet




Modular Network Connector

For modular cable connections in a Crestron remote control system, the six-conductor modular cable is used to power Crestron devices. That cable must be rated for 30

VDC, 140°F (60°C) minimum. Also, the cable must be rated to carry sufficient current for the loads. UL style 20251 cable can be used to carry up to 2A when used in a dual power and dual ground configuration, as shown below.

Crestron Network Modular Cable Requirements



NOTE: Most 6-conductor phone cables are wired in a crisscross fashion and are not compatible with Crestron equipment.

Hardware Hookup


Refer to the hookup diagram on the next page and aside from attaching power last, complete the connections in any order.

NOTE: Refer to the latest revision of the Crestron Network Modular Cable Requirements (Doc. 5682) or Network Interconnect Drawing (Doc. 5411) when making connections to the port labeled CRESNET. These documents can be obtained from the Downloads page (CABLES and MANUALS Libraries) of the Crestron website (www.crestron.com). Search for the MODULAR.PDF and CRESNET.PDF files, respectively.

NOTE: To prevent overheating, do not operate this product in an area that exceeds the recommended ambient temperature of 104°F (40°C). Consideration must be given if installed in a closed or multi-unit rack assembly since the operating ambient temperature of the rack environment may be greater than the room ambient. Contact with thermal insulating materials should be avoided on all sides of the unit.

NOTE: The maximum continuous current from equipment under any external load conditions shall not exceed a current limit that is suitable for the minimum wire gauge used in interconnecting cables. The ratings on the connecting unit's supply input should be considered to prevent overloading the wiring.

NOTE: Since the plug on the power supply cord is used to disconnect power from the unit, the socket-outlet shall be installed near the equipment and shall be easily accessible.

Hookup connections for CNMSX

Programming the LCD Display (available on CNMSX-PRO only)

NOTE: The following description assumes that the reader has some knowledge of SIMPL™ Windows®. If not, please refer to the extensive help information provided with the software.

SIMPL (Symbol Intensive Master Programming Language) is an easy-to-use programming language that is completely integrated and compatible with all Crestron system hardware. The objects that are used in SIMPL are called symbols. SIMPL Windows offers drag and drop functionality in a familiar Windows® environment.

SIMPL Windows is Crestron Electronics development environment for programming Crestron control systems. It provides a well-designed graphical environment with a number of workspaces (i.e., windows) in which a programmer can select, configure, program, test, and monitor a Crestron control system.

The CNMSX-PRO LCD display is preprogrammed with a certain level of diagnostic, testing, and network device information. Assuming the CNMSX is connected to a PC running SIMPL Windows, a LCD display programming utility (Front Panel Editor) can be accessed. This editor enables a programmer to program multi-level pages under the PANEL (left-most, function) button on the LCD display.

Front Panel Editor

The LCD display on a CNMSX-PRO has different pages that are defined by the programmer. Menu function buttons are assigned to different pages or objects. The LCD display has a 2x40 character display with six-programmable buttons.

In Front Panel Editor, pages are designed and added to the panel. An example of the default page is shown after this paragraph. Each front page is one display (2x40 characters) and can have as many objects as the physical size of the display allows (objects can not overlap). The top line of the panel is used for informative object displays, such as headings, indirect text, bar graphs, and time/date displays. The bottom line of the panel is for objects that are accessed by the six menu function buttons below the display. The buttons only access the page or object whose field is directly over the button. Objects added to the bottom line of the display can have

page jumps or logic programming in SIMPL Windows that cause specific events to occur. These objects are initiated by pressing the function button that is associated with it.

Default Front Panel Page



Creating a Simple Page with Front Panel Editor

NOTE: The creation of a basic page is discussed in this section. For more details, consult the SIMPL Windows help file. Search for Front Panel Editor.

Assume that a page, as shown on the next page, is required. The concept of such an application is that the user can then choose a given device and then, from a lower-level page, control one or more transport functions of the device.

Example of a Front Panel Page



Adding Top-Level Pages and Objects

Use SIMPL Windows and access the Front Panel Editor by selecting **Project | Edit Front Panel**. Click on the **Add** button and enter a new name for the new page. For this example, use “Menu1 – Choose Device” as the name.

Double click inside the display area of the front panel on the screen to open the “Edit Panel Object” dialog box. This sample requires that headings be added to the page, so choose **Text Object** from the *Object Type* area. In the *Inactive Text* field, enter “Choose device”. The object is displayed on the panel. Click on and drag the object to its desired location on the panel, top row.

Add additional objects (VCR, LaserDisc, CD, Lights, and Volume) to the page by double clicking in the display area where the object is to appear. Repeat the procedure in the previous paragraph; place objects over the appropriate menu function button.

Adding Lower-Level Pages and Objects

Lower-level pages can be added for each of the objects on the bottom row of the page just created. For the purposes of this example, one lower-level page is added for the VCR object. Simply click on the **Add** button and enter a new name for the new page. For this example, use “Menu2 – VCR Control” as the name.

Return to the “Menu1 – Choose Device” and double click on the VCR object. The “Edit Panel Object” dialog box appears. From the *Menu Jump* field, select “Menu2 – VCR Control” and click **OK**. Select the **Simulate** check box to make the Front Panel Editor simulate an actual CNMSX-PRO front panel. Click on the VCR function button to enable the simulated page jump. The display clears, because “Menu2 – VCR Control” has been named, but no objects have been added yet.

An example VCR Control page, as shown below, has a text object that appears as a header on the top row of the display and objects that are control functions assigned to each function button. Objects in the bottom row are shown in the inactive state (none of the buttons are being pressed).

Example VCR Control Page




Use the “Edit Panel Object” dialog box to add objects to this page. Double click on the first object, **play**. From the *Digital Channel* field in the “Edit Panel Object” dialog box, scroll down to or enter “1”. In the *Active Text* field, enter “PLAY” as the button’s active text. Therefore, when the menu function button associated with digital channel 1 (the VCR button) is pressed, the active text is displayed as a visual cue that the button is pressed. Do the same procedure for each of the other menu function buttons in the “Menu2 – VCR Control” page.

NOTE: Digital channels are also referred to as “join numbers”. Join numbers are numeric identifiers assigned to an object or button. It is necessary to identify objects so the input/output signals of the SIMPL program can be named and routed properly.

Front Panel Symbol

A powerful tool to assist programmers in naming and routing signals for the LCD display is the **Synchronize Signals** command. While the panel appears on the PC screen, select **Panel | Synchronize Signal Names** to automatically name all the input and output signals for the front panel in the SIMPL Windows program. To display the signal names, double click on Slot-08 : CNX LCD Front Panel which is available from the Central Control Modules folder in the *Program View* of SIMPL Windows’ Program Manager. The symbol appears in *Detail View*, as shown after this paragraph.

Front Panel Symbol Displayed in SIMPL Windows’ Detail View of Programming Manager



Object Types

The sample discussed in the previous sections utilizes only one of the object types available from the “Edit Panel Object” dialog box, shown below. These object types are not new to Crestron programmers; the same types are available in VisionTools™ Pro-e. For a detailed description of these types refer to the VisionTools™ Pro-e help file. Use the glossary or search function to locate the information.

Object Type Area in the “Edit Panel Object” Dialog Box



Loading Crestron Control Software

Crestron control software is available in an electronic form, via CD-ROM, email, or from the Crestron website (www.crestron.com). Regardless of how and from where the software is obtained, this section provides the necessary installation steps.

Before performing the following set of instructions, obtain a straight-through RS-232 cable that has a DB9 male connector on one end and a DB9 female connector on the other. Straight-through means that pin 1 on the male end goes to pin 1 on the female end, etc. The male end plugs into the port labeled COMPUTER on the CNMSX. The female end plugs into a serial port on the PC. If the PC has a DB25 male connector, obtain a DB9 to DB25 adapter (the adapter has a DB9 male end and a DB25 female end).

Installing Crestron Development Tools

Crestron provides software tools for programming the CNMSX. Even if only the control software is being loaded into the hardware and there are no plans to do any programming, some Crestron development software must be installed on the PC. Currently, Crestron programming is accomplished with the use of the following development tools listed in the table below.

NOTE: If the intent is to load software developed by someone else, then install SIMPL Windows only. Install all three applications to program systems as well.

NOTE: The latest version of these applications is available from the Crestron website (www.crestron.com). Crestron ControlCD also carries a version (which may not be as current as the website version). To obtain a free copy of the CD-ROM, please call Crestron at 1-888-CRESTRON [1-888-273-7876]. Alternatively, complete a literature request from the Crestron website to obtain one.

Crestron Development Tools

DEVELOPMENT TOOL	DESCRIPTION
SIMPL™ Windows®	Used to program the main control processor.
VisionTools™ Pro-e	Used to design touchpanel layouts and to program SmarTouch Systems.
DEAL™ for Windows®	Used for learning (using the optional CNXLIR) and maintaining IR driver files.

Before installing any tools, confirm that all applications such as Microsoft Office, etc. are not running and are closed. The website and CD provide instructions for installing the various development tools. When initiating a custom install from the CD, the user is presented with a list of the software programs, documentation, and other resources available on the CD-ROM. For each item, set or clear a checkbox to the left of the item to direct the installation program whether to install that component onto the hard drive. The size of the items installed determines how much hard disk space is required.

Each development tool contains a help file that can be opened from the Help pull-down menu. Refer to these files for additional information.

Initial Setup

NOTE: For the Ethernet IP setup of the CNMSX with optional CNXENET+ Ethernet Expansion card, refer to the CNXENET+ Operations & Installation Guide (latest revision of Doc. 8153) for further information.

To avoid any procedural errors, follow the steps in the order provided.

After installing the desired development tool, various job files may be obtained from Crestron or other sources. Using Windows Explorer, complete the following steps. These steps ensure that all job files reside on the hard drive (C:) in a directory named \CRESTRON\PROJECTS\MYJOB.

1. Navigate to the SIMPL directory on the hard drive. Assume that the default install directory is C:\CRESTRON.
2. Create a new folder for the project files. Although the folder where the files are placed is not critical, it is easier to manage projects if a logical structure is created. For example, create a new folder, called PROJECTS, underneath the CRESTRON directory. Create another folder, called MYJOB, under PROJECTS for the current job. The resulting pathname is C:\CRESTRON\PROJECTS\MYJOB.
3. Copy the supplied files into the folder created in the last step. The source of the file determines the procedure.


From a floppy disk: Most floppy disks sent from Crestron contain a common directory structure designed to make it easier to organize files. Copy the entire contents of the disk(s) including the directory structure.

From an EXE file: If a job is downloaded from the Crestron website or is received via email, all files may have been compacted into a single, self-extracting archive. This archive has an EXE extension. First, copy the EXE file into the directory stated in step 1, then double click on the file name to begin decompressing the file. The program asks for a location for the extracted files. In this case, simply browse for the same directory where the archive was copied. (Once files are extracted, retain the original EXE file in case files need to be restored at any point.)

From a ZIP file: If the downloaded job is from the Crestron website, BBS, or email, all files may have been compressed into a single archive file with a ZIP extension.


If the program was created with SIMPL Windows 1.30.01 or later, this file was created with the Copy Program feature of SIMPL Windows, which provides the option to archive the project to a ZIP file. An example dialog box is shown on the next page.

Copy Program Dialog Box



- After **Begin Copy** is selected, the selected files will be archived to the example file C:\CRESTRON\SIMPL\PROGRAMS\EXAMPLE.ZIP. For this ZIP file to be used by SIMPL Windows, select **File | Import Archived Program** from the Crestron Viewport. This will present a dialog similar to the one below, after selecting the ZIP to import.

"Import an Archived Program" Dialog Box




The job may be copied to any folder or directory, and the User IR, Macro, and SIMPL+ files will be copied to the proper directories. If a version of SIMPL Windows lower than 1.30.01 is being used, copy the ZIP file into the job directory stated in step

1, then extract the files with a program called WinZip. Obtain a copy of this program from their website (www.winzip.com) on the internet. Extract the files into the same directory where the archive was copied. Once files are extracted, retain the original ZIP file in case the files need to be restored at any point. The User IR, Macro, and SIMPL+ modules will need to be copied to their proper directories manually.

File Types

There are quite a few file types involved with Crestron control software. This section is intended to explain the different file types that might be encountered in each directory. In many cases, the supplied software is grouped into a number of subdirectories. The intent is to keep files organized. For example, after copying the files to the hard disk, the directory structure *may* appear as shown below.

Possible Subdirectory Structure



NOTE: In this structure, the "VT3501" and "VT3502" directories represent two VT-3500 touchpanels that are part of the entire remote control system. Please consult the connection sheets or other supplied information to determine which directory corresponds to a given touchpanel.

Ops Subdirectory - The files in this subdirectory contain the CNMSX operating system with which the program was tested. Ensure that the operating system version currently loaded is equal to or newer than the version included here, so that the program runs properly. For help with uploading an operating system, refer to "Updating the Control System" on page 31.

File Types in Ops Subdirectory

FILE TYPE	DESCRIPTION
.upz	This is a control system file. For more information regarding these files, refer to "Updating the Control System".

Programs Subdirectory - The files in this subdirectory (shown on the next page) contain the system program. This is the main program which loads into the CNMSX and determines the exact functionality of the system.

File Types in Programs Subdirectory

FILE TYPE	DESCRIPTION
.asv	SIMPL Windows auto-save file.
.bin	This is the executable code for all CNX control systems.
.dip	This is the default IP Table that contains the IP addresses of all of the ethernet devices in the system. It is generated when the program is compiled and the CNX control system contains an optional CNXENET+ expansion card and Ethernet devices.
.sig	This file contains information required by Test Manager (see SIMPL Windows help for more information) for debugging programs in real-time. It is generated each time the program is compiled.
.sm2	SIMPL Windows program backup file.
.smp	This is the SIMPL-C file that is generated from the SMW file when a program is compiled. In SIMPL Windows version 1.18 or lower, this file is what actually gets compiled into the BIN file. In versions after 1.18, this file may or may not be generated and is not required.
.smw	This is the SIMPL Windows program file. It contains the source code for the main system program.

Userdb Subdirectory - The files in this subdirectory are user database infrared (IR) drivers, which are needed to interface with certain IR-controlled devices in the system. These differ from Crestron database IR drivers in that the former are included as part of a Crestron Database release.

File Types in Userdb Subdirectory

FILE TYPE	DESCRIPTION
.ir	This is a user IR driver file. It is needed during the convert/compile process in order to properly compile the program. If recompilation of the program is necessary, use the Import Program option or copy any IR files received into the default user database directory (see SIMPL Windows help for more information). Alternatively, set the SIMPL Windows userdb directory to the directory where the macros exist. In SIMPL Windows, this is accomplished from the Directories tab by selecting Edit Preferences .

Usrmacro Subdirectory - The files in this subdirectory are user macros, or special sub-programs that are integral parts of the main program. These differ from Crestron macros in that the former are supplied as part of the development software.

File Types in Usrmacro Subdirectory

FILE TYPE	DESCRIPTION
.um2	This is the user macro backup file.
.umc	This is a user macro file. It is needed during the convert/compile process in order to properly compile the program. To recompile the program, use the Import Program option or copy any UMC files received into the default user macro directory (see SIMPL Windows help for more information). Alternatively, set the SIMPL Windows usrmacro directory to the directory where the macros exist. In SIMPL Windows, this is accomplished from the Directories tab by selecting Edit Preferences .

UsrSPlus Subdirectory - The files in this subdirectory (shown on the next page) contain the User SIMPL+ modules used in this system. To recompile the program, use the Import Program option or copy the USP and USH files received into the default user SIMPL+ directory. Alternatively, set the SIMPL windows user SIMPL+ directory to the directory where the USP and USH files exist.

File Types in UsrSPlus Subdirectory

FILE TYPE	DESCRIPTION
.csz	Crestron SIMPL+ archive. This archive contains all of the SIMPL+ executable code (from both user modules and crestron modules) that the Transfer Program dialog will send to the CNMSX.
.uf	User SIMPL+ compiled file. This contains the executable SIMPL+ code for the CNMSX.
.usp	User SIMPL+ source code module. This file gets compiled by the SIMPL+ environment and also is editable by the user.
.ush	User SIMPL+ header file. This file details how SIMPL Windows should model the gate as a symbol (i.e. how many inputs, outputs, etc.).

Touchpanel Subdirectory - The files in this subdirectory contain touchpanel projects (for example, “vt3501” and “vt3502” in the previous illustration titled “Possible Subdirectory Structure”). Each project describes the exact graphical nature of the panel to which it uploads.

File Types in Touchpanel Subdirectory

FILE TYPE	DESCRIPTION
.bmp, .pcx, or .dib	These are graphic files that are needed by VTW for recompiling touchpanel projects.
.hex	This is the compiled touchpanel project file. This file is uploaded to the panel itself.
.lgc	Logic files for existing SmarTouch products, like ST-1500/1500C, that use VTW.
.vti and .vtl	Logic files for existing SmarTouch products, like ST-1500/1500C or ST-1550/1550C that use VTPro-e.
.vtp	This is the only VisionTools Pro-e (VT Pro-e) file required for a given project. It replaces the PRJ, PGF, and graphic (BMP, PCX, etc.) files that were part of VisionTools for Windows (VTW) projects.

Obtaining Communications


NOTE: If optional CNXENET+ Ethernet Expansion Card is installed into the CNMSX, communications can be obtained over TCP/IP. The CNXENET+ Operations & Installation Guide explains how to load the required IP Table that contains the addresses of the Ethernet devices and set up the control system for Ethernet communications. Refer to the CNXENET+ Operations & Installation Guide (latest revision of Doc. 8153) for further information.

Before attempting to upload the program files into the CNMSX, it is necessary to first establish communication between the CNMSX and a PC. There are two ways of communicating with the CNMSX, either via the COMPUTER port (RS-232 serial communications) or via Ethernet if optional CNXENET+ Ethernet Expansion card is installed. Prior to completing the following steps, be sure the communication cable is properly connected as described in "Loading Crestron Control Software" on page 18.

1. Make sure that no programs accessing the COM port of the PC are running.
2. Select **Start | Programs | Crestron | SIMPL Windows** to start SIMPL Windows.
3. SIMPL Windows responds with an opening splash screen and may display the “What do you want to do?” dialog box. If so, close the dialog box.


- As illustrated after this step, select **Tools | Viewport** to open the “Crestron Viewport” dialog box.

Accessing the Viewport




- From the **Setup** menu, verify that **Auto Baud Search** is checked; refer to illustration below.

Verifying Auto Baud Search




- While the Viewport is displayed, select **Setup | Communications settings** (alternatively, depress **Alt+D**) to open the “Port Settings” dialog box. Refer to the illustration on the next page.

Accessing the “Port Settings” Dialog Box



7. Select the appropriate connection type (RS-232 for a PC connection through the COMPUTER port of the CNMSX or TCP/IP through the Ethernet via optional LAN/DPA port). Verify that the proper COM port is selected. Set the baud rate to **38400**, the parity to **None**, the data bits to **Eight**, and the stop bits to **One**. Refer to the dialog box shown after this step for the remaining settings. Click on the **OK** button to save the communication settings and close the dialog box.

“Port Settings” Dialog Box



8. Select **Diagnostics | Check Operating System Version** (alternatively, depress the **F5** key) from the Viewport. The Viewport may display a window as it scans various baud rates. Eventually, a message should appear in the *Incoming* section showing a version number. Such a response indicates that communications have been established. If a “No Communications with Rack” error message appears, proceed to “Troubleshooting Communications” on page 26.
9. If the baud rate of the CNMSX was something other than 38400, then the software automatically adjusts the baud rate to 38400.


Troubleshooting Communications

NOTE: This section covers troubleshooting communications of the CNMSX via RS-232 to the COMPUTER port. For troubleshooting Ethernet communications of the CNMSX with optional CNXENET+ Ethernet Expansion Card, refer to the CNXENET+ Operations & Installation Guide (latest revision of Doc. 8153) for further information.

If communications with the CNMSX was not established, follow the steps in this section to help remedy the problem. After performing each step, repeat step 7 in “Obtaining Communications” on page 23 again.


1. Try repeating step 7 from “Obtaining Communications” on page 23 to attempt to establish communications.
2. Verify that the cable being used is correct. It should be a straight-through cable. That is, pin 1 on one end is connected to pin 1 on the other end. Pin 2 connects to pin 2, etc. To work properly, pins 2, 3, and 5 must be connected.
3. Verify that the proper COM port on the PC has been selected. Some computers have more than one COM port; some of which may be internal (e.g., for a modem). If verification can not be made, consult the user’s manual or contact the PC manufacturer.
4. Check the **ACTIVITY** and **SYSTEM ERROR** LEDs on the front of the CNMSX. If either LED is illuminated, unplug the unit and reapply power after a few seconds. If either LED illuminates again, call Crestron technical support. Refer to “Further Inquiries” on page 36.
5. If steps 1 through 4 have failed to result in communications, the last series of steps to perform is an overload/reset on the control processor. Complete the following steps to do so.
 - 5a. While the Viewport is displayed, select **Setup | Communications Settings** (alternatively, depress **Alt+D**) to open the “Set Baud Rate” dialog box.

Accessing the Set Baud Rate Dialog Box



5b. Set the baud rate to 9600, as shown below.

Changing the Baud Rate from the “Set Baud Rate” Dialog Box



5c. Set the CNMSX to 9600 baud.

- Depress and hold the **SW-R** button on the CNMSX front panel.
- Depress and release the **HW-R** button on the CNMSX front panel.
- Wait until a message similar to the one below appears in the Viewport.

Viewport Message

```
MSX Monitor v1.44 * 1/20/00 - interupt serial i/o
512k flash memory, 512k NVRAM, segment=FC00
Press <esc> now to enter debug monitor
```

NOTE: If a computer is not hooked up, wait approximately three to four seconds.

- Release the **SW-R** button.
- 5d. If the CNMSX responds, proceed to step 5e. Otherwise, do the following.
- Remove power from the CNMSX.
 - Depress and hold the **SW-R** button on the CNMSX front panel.
 - Reapply power to the CNMSX.
 - Wait until a message similar to the one below appears in the Viewport.


Viewport Message

```
MSX Monitor v1.44 * 1/20/00 - interrupt serial i/o
512k flash memory, 512k NVRAM, segment=FC00
Press <esc> now to enter debug monitor
```

NOTE: If a computer is not hooked up, wait approximately three to four seconds.

- Release the **SW-R** button.
- 5e. Text messages, as shown below, should appear on the *Incoming window* of the Viewport. If messages do not appear or they are illegible, verify that the Viewport is set to 9600 baud and repeat steps 5a through 5d. If data similar to that shown below appears, perform steps 7 through 11 in "Obtaining Communications" on page 23 before proceeding to the next step.

Crestron Viewport – Outgoing and Incoming Window



NOTE: The exact text received depends on the given CNMSX hardware.

- 5f. Remove power from the unit again and reapply power *without* holding the **RESET** button down. Wait a few seconds and perform step 7 in "Obtaining Communications" on page 23.


NOTE: If after trying all these procedures, communication can not be established, contact Crestron technical support for assistance. Refer to "Further Inquiries" on page 36.

Loading the System Program

To load the system program into the CNMSX, use the Crestron Viewport or the Transfer Program option in SIMPL Windows. For consistency, the steps that follow this paragraph use the Viewport. To upload a BIN file into the CNMSX, complete the following steps in the order provided.

1. Select **Tools | Viewport** to open the "Crestron Viewport" dialog box, if it is not already opened.
2. Select **File Transfer | Send Program** (alternatively, depress **Alt+P**) to open the "Cresnet Simpl Program" dialog box.
3. Use the **Browse** button to locate the supplied BIN file.
4. As shown after this step, click the **Send Program** button to initiate program upload to the CNMSX. A Transfer in Progress dialog box opens, but no response is required. If SIMPL+ files are present and the SIMPL+ Program(s) option is checked in the "What to Send" field, the associated files will be transferred after the program is transferred.

"Cresnet Simpl Program" Dialog Box



NOTE: The permanent memory image is the program stored into flash memory. From the image, the program can be recalled automatically if power to the unit is lost or interrupted. Permanent memory can be overwritten as many times as needed.

5. When a "Query" dialog box opens to create the permanent memory image, click **Yes**. A "Success" dialog box opens when the permanent memory image is complete. If the "Failure" dialog box opens, repeat steps 3 and 4. If this does not remedy the problem, call Crestron technical support. Refer to "Further Inquiries" on page 36.

NOTE: Not normally required, the **Make Permanent** button also creates a permanent memory image.

6. After transferring the program file, click on the **Check Program** button to ensure that the file loaded properly. The information in the *Current Program* field of the "Cresnet Simpl Program" dialog box should update and display the file currently loaded. If the information does not update, repeat steps 3 through 5. If this does not remedy the problem, call Crestron technical support. Refer to "Further Inquiries" on page 36.

Testing the Permanent Memory Image

Complete the following steps in the order provided to test the permanent memory image.

1. Select **Tools | Viewport** to open the "Crestron Viewport" dialog box.
2. Unplug the CNMSX and leave it unplugged for about 10 seconds.
3. Plug the unit in and observe the statistics displayed in the Viewport *display field*. The program name uploaded into the system also appears.
4. Verify the displayed information against what was originally loaded when the unit was shipped.

Loading Touchpanels

The CNMSX may include one or more touchpanels. Each panel must be set to the proper network ID and loaded with a touchpanel *project* in order to work properly in conjunction with the system program loaded in "Loading the System Program" on page 29. For each panel in the system, a separate HEX file describing the graphical elements of the panel is required. In some cases, where two or more panels are to be identical in usage, a single HEX file may be used for multiple panels. To load a touchpanel project into the panel, use the Crestron Viewport or the "Upload Project" function in VisionTools™ Pro-e. For consistency, the steps that follow this paragraph use the Viewport. To upload a HEX file into the touchpanel, complete the following steps in the order provided.

1. Verify that the touchpanel is connected to the CNMSX via the appropriate network cable. Also, verify that the touchpanel is set to the proper network ID. (This info should be available in the system connection sheets or directly from the programmer.)
2. Select **Tools | Viewport** to open the "Crestron Viewport" dialog box, if it is not already opened.
3. Select **Diagnostics | Report Network Devices** (alternatively, depress F4) and verify that the touchpanel to be loaded reports back and is at the expected network ID.
4. Select **File Transfer | Send Touchpanel** (alternatively, depress **Alt+T**) and set the network ID to the ID of the touchpanel to be loaded.
5. Browse for the supplied HEX file and click the **Open** button. The file is sent to the CNMSX and then over the network to the touchpanel. Verify that the panel displays a message saying that the upload is in progress.

Updating the Control System


Each CNMSX contains an operating system (OPS), a Monitor ROM, and when the optional CNXENET+ Ethernet Expansion Card is installed, a TCP/IP Stack. Although each is a separate component, they are packaged together in a control system update file. Control system update files have the UPZ extension. It is often necessary to update a control system if new features have been implemented (such as support for new hardware or new language constructs) or if bugs have been corrected. The following procedure is recommended to load a new UPZ file into the CNMSX:

NOTE: UPZ files only pertain to X generation control systems and are not used for older models such as the CNRACK, CNMS, CNLCOMP-232, or ST-CP. Consult the appropriate documentation for each of these products to perform updates.

NOTE: In order to load the latest update files, the CNMSX must have v2.05 or later (this includes v5.01.35 or later) of the Monitor ROM. This requirement should only impact a few users; refer to "Special Consideration for Updating the Control System" on page 33 for details.


1. Establish communications with the CNMSX by following the steps listed in "Obtaining Communications" on page 23.
2. From the Crestron Viewport, select **File Transfer | Update Control System** as shown below.

Accessing the "Update Control System" Dialog Box




3. The "Update Control System" dialog box, shown on the next page, offers the option to enter the path name of a new update file. If the path name is not known, use the **Browse** button to navigate to a list of available update files. When browsing, choose only update files with a UPZ extension.

"Update Control System" Dialog Box



4. After a file is selected, the "Update Control System" dialog box, as shown after this step, will query the CNMSX to determine what versions of the Operating system, Monitor ROM, and TCP/IP Stack are currently running.


Example of "Update Control System" Dialog Box



5. If the CNMSX does not have the optional CNXENET+ Ethernet Expansion Card, uncheck the TCP/IP Stack option to transfer faster (transferring the stack will not cause any problems). Otherwise, send all of the checked components. To start the transfer, click the **Send** button. The transfer dialog will inform you of the progress in updating the selected components.

- As a result of the update, a dialog box similar to below may open and the SIMPL program (and possibly SIMPL+ modules) must be cleared.

"Continue with transfer?" Selection Box




- Upload the SIMPL program and SIMPL+ modules after the transfer is complete.

Special Consideration for Updating the Control System

This special consideration only applies to early production CNMSX units. These early units cannot be updated directly without updating an intermediary Monitor ROM first. If the CNMSX being updated has a Monitor ROM prior to v2.05 (this includes Monitor ROM 5.01.35 and lower), a dialog box shown below appears when attempting to update the control system.

"Continue with transfer?" Selection Box



One can avoid jumping into the updating process by checking if the CNMSX has v2.05 or later (or v5.01.35 or later). Simply reboot the CNMSX while in Viewport. Either cycle the power, depress the **HW-R** button on the front panel, or select **Functions | Cold Reboot**. The initial boot message appears and may be similar to the following. Notice that the Monitor ROM version is displayed in the first line.

Viewport Message

```
MSX Monitor v5.01.35 * 1/20/00 - interupt serial i/o
512k flash memory, 512k NVRAM, segment=FC00
Press <esc> now to enter debug monitor
```

If the CNMSX has an early Monitor ROM, update the CNMSX by first using the 50135x.upz file from the Crestron website (OPSYS Library). This UPZ file has no TCP/IP stack, so the checkbox for the TCP/IP stack is unavailable (grayed out).

Finally, update to the latest UPZ file as listed in the OPSYS Library. The specific steps are provided in "Updating the Control System" on page 31.

Problem Solving

Problems may occur with the CNMSX itself or there may be serial communication difficulties with other devices connected to the CNMSX. The next two sections address possible problem solving tools or procedures for each.

Possible Problems with the CNMSX

Troubleshooting the CNMSX

The table following this paragraph provides corrective action for possible trouble situations. If further assistance is required, please contact a Crestron technical support representative.

CNMSX Troubleshooting

TROUBLE	POSSIBLE CAUSE(S)	CORRECTIVE ACTION
Unexpected response from CNMSX.	Network devices are not communicating to the CNMSX.	From the Viewport, poll the network (F4) to verify communication.
PWR LED does not illuminate.	CNMSX is not receiving power.	Verify that supplied power cord is properly attached to CNMSX and the other end is securely plugged into an outlet.
NET LED does not illuminate.	Improper NET ID.	Verify that CNMSX NET ID matches NET ID in SIMPL Windows program.
	SIMPL Windows program error.	Verify the SIMPL Windows program.
	Loose network connection.	Verify that cables attached to CNMSX CRESNET connectors are proper and secure.
ERR LED illuminates.	Hardware or software failure, hardware incompatibility with software definitions, or programming error.	Verify that hardware configuration matches software configuration (i.e., card is in proper slot as defined by program). If using PRO, depress MSG button on front panel for specific error. If using AV, poll the network (F4) from the Viewport.
A/V system device does not respond.	CNIRP or serial port not placed properly.	Verify placement of CNIRP (hold phosphor card under CNIRP while pressing button) and tighten serial cables.
	Used wrong IR or serial port.	Verify that proper IR or serial port is defined.

Network Analyzer (available on CNMSX-PRO only)


To assist with troubleshooting, the unit contains Crestron’s patent-pending network analyzer to continuously monitor the integrity of the Cresnet network for wiring faults and marginal system performance or other network errors. For more information on how to use the network analyzer, refer to the SIMPL™ Windows® help file and use the index to search for "Network Analyzer".

Serial Communication Difficulties with Other Devices Connected to the CNMSX

Passthrough Mode

Passthrough mode is accessed from the Crestron Viewport by selecting **FUNCTIONS|ENTER PASSTHROUGH MODE (CNX ONLY)**. The dialog box, shown on the next page, is used to select the port configuration for passthrough mode.

Passthrough Mode Dialog Box



Passthrough mode allows data to pass from the COMPUTER port to the selected COM port. While passthrough mode is running, the program currently in memory is suspended and will not execute. When passthrough mode is exited, the program resumes operation. The TX and RX LEDs for the given port illuminate when in passthrough mode.

Entering passthrough mode for one of the internal COM ports reinitializes it, which clears the data for that port. The COM analyzer also functions while the unit is in passthrough mode.

COM Analyzer (CNMSX-PRO only)

NOTE: The COM Analyzer feature is not available for external COM cards.

Release of the CNX Operating System (version 5.01.05 or later) supports a communications (COM) analyzer function to examine serial data transmitted to and received from any of the six internal serial ports only. Complete the following steps to access the COM Analyzer.

1. From the front panel Main Menu (default front panel page), press the COM menu function button.
2. From the next menu, press the menu function button associated with one of the six COM ports. The six ports are A through F, as labeled on the rear panel of the CNMSX-PRO.
3. The Format Selection Menu appears, as shown below. BIN, ASCII, and HEX control how data is to be displayed on the T/R screen. Depressing either of the three data formats jumps to the T/R screen.

Format Selection Menu



Since there is no room on the T/R screen for button text, RESET and RFSH (refresh) are provided on the Format Selection Menu to show their location on the T/R screen.

RESET resets the display buffers for both transmit and receive. An empty buffer is indicated by the phrase “*Display Buffer Clear*” in the T/R screen. Pressing BIN, ASCII, or HEX displays the screen shown on the next page.

T/R Screen



The top line of the T/R screen displays data that is transmitted out the selected ports in the selected format. The bottom line displays the data that is received in the selected format. If more data is present in the display buffer, only the most recent data is displayed (older data scrolls off the screen).

Since there is no room on the T/R screen for button text, RESET and RFSH are provided on the Format Selection Menu to show their location on the T/R screen.

A RFSH function is provided to read the front panel data at your own pace. Without this function, data would constantly scroll by on the display. At the moment the T/R screen is accessed, a “snapshot” of the display buffer contents appears. New data entering the display buffer is not displayed until the RFSH menu function button is pressed.

NOTE: It is very easy to switch the format of the displayed data. Press the **MENU** button along the right side of the LCD display to return to the Format Selection Menu. Make a selection to display the data in the new format. Since the buffers are not erased until the RESET menu function button is pressed, the same data is viewable in all three formats.

Further Inquiries

If after reviewing this Operations Guide, you cannot locate specific information or have questions, please take advantage of Crestron's award winning technical support team by calling:

- In the US and Canada, call Crestron's corporate headquarters at 1-888-CRESTRON [1-888-273-7876] or 1-201-767-3400.
- In Europe, call Crestron International at +32-15-50-99-50.
- In Asia, call Crestron Asia at +852-2341-016.
- In Latin America, call Crestron Latin America at +525-574-15-90.

For local support from exclusive Crestron factory-trained personnel call:

- In Australia, call Soundcorp at +613-9488-1555.
- In New Zealand, call Amber Technologies at +649-410-8382.

Return and Warranty Policies

Merchandise Returns / Repair Service

1. No merchandise may be returned for credit, exchange, or service without prior authorization from CRESTRON. To obtain warranty service for CRESTRON products, contact the factory and request an RMA (Return Merchandise Authorization) number. Enclose a note specifying the nature of the problem, name and phone number of contact person, RMA number, and return address.
2. Products may be returned for credit, exchange, or service with a CRESTRON Return Merchandise Authorization (RMA) number. Authorized returns must be shipped freight prepaid to CRESTRON, Cresskill, N.J., or its authorized subsidiaries, with RMA number clearly marked on the outside of all cartons. Shipments arriving freight collect or without an RMA number shall be subject to refusal. CRESTRON reserves the right in its sole and absolute discretion to charge a 15% restocking fee, plus shipping costs, on any products returned with an RMA.
3. Return freight charges following repair of items under warranty shall be paid by CRESTRON, shipping by standard ground carrier. In the event repairs are found to be non-warranty, return freight costs shall be paid by the purchaser.

CRESTRON Limited Warranty

CRESTRON ELECTRONICS, Inc. warrants its Cresnet products, denoted by a "CN" prefix model number, to be free from manufacturing defects in materials and workmanship for a period of three (3) years from the date of shipment to purchaser. Disk drives and any other moving or rotating mechanical parts are covered for a period of one (1) year. CRESTRON warrants all its other products for a period of one year from the defects mentioned above, excluding touchscreen display components which are covered for 90 days. Incandescent lamps are completely excluded from Crestron's Limited Warranty. CRESTRON shall, at its option, repair or replace any product found defective without charge for parts or labor. Repaired or replaced equipment and parts supplied under this warranty shall be covered only by the unexpired portion of the warranty.

CRESTRON shall not be liable to honor warranty terms if the product has been used in any application other than that for which it was intended, or if it has been subjected to misuse, accidental damage, modification, or improper installation procedures. Furthermore, this warranty does not cover any product that has had the serial number altered, defaced, or removed.

This warranty shall be the sole and exclusive remedy to the purchaser. In no event shall CRESTRON be liable for incidental or consequential damages of any kind (property or economic damages inclusive) arising from the sale or use of this equipment. CRESTRON makes no other warranties nor authorizes any other party to offer any warranty, expressed or implied, including warranties of merchantability for this product. This warranty statement supersedes all previous warranties.

Trademark Information

All brand names, product names, and trademarks are the sole property of their respective owners. Windows is a registered trademark of Microsoft Corporation. Windows95, Windows98 and WindowsNT are trademarks of Microsoft Corporation.



Crestron Electronics, Inc.
15 Volvo Drive Rockleigh, NJ 07647
Tel: 888.CRESTRON
Fax: 201.767.7576
www.crestron.com

*Specifications subject to
change without notice.*

Doc. 8118A
02.00